


# ***ENG 4550 – Introduction to Control Systems***

## ***Lab 2***



## **Lab 2: SRV02 Modeling Part 2 – Bump Test & Model Validation Experiment**

- Please use the same SRV02 as the one in your Lab1.
- In 'ENG4550 control systems' on desktop, unzip 'Lab MatlabSimulink Software-20181001.zip' to a **NEW DIRECTORY**. All files you need in Lab 2 are in .../NEW DIRECTORY/Modelling (LAB 1 and 2)



- When complete, **DELETE/REMOVE** your files and the **FOLDER** you created.

## 1. Configuring the SRV02 according to Section 1.4.2 in Workbook.

- Setup q\_srv02\_mdl.mdl: Double-click on the QUARC HIL Initialize block. Select the data acquisition device (q2\_usb or q8\_usb) you are using. Click on the **Defaults** and **OK** button.
- In setup\_srv02\_exp01\_mdl.m, make sure MODELING\_TYPE is set to '**MANUAL**'. Run setup\_srv02\_exp01\_mdl.m.

## 2. Follow the steps in **Section 1.3.2 Bump Test Experiment**.

- Before building the model (Step 5), click QUARC -> Set Default Options to avoid the possible target error.

**Typos: Update Diagram is in Simulation menu, not Edit menu. (In Steps 8, 10)**

**Ignore all contents about Nominal values or model in Steps 12, 14, 15, 16, Table 1.2 and your Lab report.**

## **1. Follow the steps in Section 1.3.3 Model Validation Experiment.**

- Before building the model (Step 4), click QUARC -> Set Default Options to avoid the possible target error.

## 1. Lab report (Lab 1 & Lab2)

- Finish your lab report according to the template in Section 1.5.1 and tips in Section 1.5.2.
- In Section 1.5.1 Template for Content  
II. RESULTS  
4. Provide data collected in this laboratory (from **Table 1.2, not 1.1**).

## 2. Pre-lab question #2

- Questions 1, 2, 3, 4, 6 and 7. (The nominal SRV02 model parameters  $K$  and  $\tau$  are 1.53 rad/(V s) and 0.0254 s, respectively.)