

ENG 4550 – Introduction to Control Systems

Lab 4



Lab 4: SRV02 Position Control

– Ramp Response Using PV Controller

What we will do in Lab 4

1. Simulation
2. Experimental test

1. Lab report (Lab 4)

- Finish your lab report according to the template in Section 2.5.2 and tips in Section 2.5.4.

II. RESULTS

Do not interpret or analyze the data in this section. Just provide the results.

1. Response plot from step 8 in Section 2.3.2.1, *Simulated PV controller with ramp input*
2. Response plot from step 8 in Section 2.3.2.2, *Ramp response of implemented PV controller*
3. Provide applicable data collected in this laboratory (from Table 2.1).

Submission of next lab

✓

✓


✓

✓

✓

Section / Question	Description	Symbol	Value	Unit
Question 4	Pre-Lab: Model Parameters Open-Loop Steady-State Gain Open-Loop Time Constant	K τ		
Question 4	Pre-Lab: PV Gain Design Proportional gain Velocity gain	k_p k_v		
Question 5	Pre-Lab: Control Gain Limits Maximum proportional gain	$k_{p,max}$		
Question 6	Pre-Lab: Ramp Steady-State Error Steady-state error using PV	e_{ss}		
Question 7	Pre-Lab: Integral Gain Design Integral gain	k_i		
2.3.1.1	Step Response Simulation Peak time Percent overshoot Steady-state error	t_p PO e_{ss}		
2.3.1.1	Filtered Step Response Using PV Peak time Percent overshoot Steady-state error	t_p PO e_{ss}		
2.3.1.2	Step Response Implementation Peak time Percent overshoot Steady-state error	t_p PO e_{ss}		
2.3.2.1	Ramp Response Simulation with PV Steady-state error	e_{ss}		
2.3.2.2	Ramp Response Implementation with PV Steady-state error	e_{ss}		
2.3.3	Ramp Response Simulation with with no steady-state error Steady-state error	e_{ss}		
2.3.3	Ramp Response Implementation with with no steady-state error Steady-state error			

- In 'ENG4550 control systems' on desktop, unzip 'Lab MatlabSimulin|Software-20181001.zip' to a **NEW DIRECTORY**. All files you need in this Lab are in .../NEW DIRECTORY/Position Control (Labs 3-5)
- When complete, **DELETE/REMOVE** your files and the **FOLDER** you created.



1. Configuring the SRV02 according to Section 2.4 in Workbook.

- In setup_srv02_exp02_pos.m, make sure CONTROL_TYPE is set to 'MANUAL'. Run setup_srv02_exp01_mdl.m.

2. Follow the steps in **Section 2.3.2.1 Simulation**.

1. Configuring the SRV02 according to Section 2.4 in Workbook.

- Setup q_srv02_pos.mdl: Double-click on the QUARC HIL Initialize block. Select the data acquisition device (q2_usb or q8_usb) you are using. Click on the **Defaults** and **OK** button.
- In setup_srv02_exp02_pos.m, make sure CONTROL_TYPE is set to '**MANUAL**'. Run setup_srv02_exp01_mdl.m.

2. Follow the steps in **Section 2.3.2.2 Implementing Ramp Response Using PV.**

- Before building the model (Step 6), click QUARC -> Set Default Options to avoid the possible target error.